

Updating the cp210x driver on Linux

Prerequisites:

DKMS should be installed on the target system.

To install DKMS on DEB systems:

```
$ sudo apt install dkms
```

To install DKMS on RPM systems:

```
$yum --enablerepo=epel install dkms
```

1. Extract the cp210x-1.0.tar at any location of your file system.
2. Open a terminal **inside** the extracted directory.
3. Run the *cp210x_install.sh* script as root.
4. Plug your cp210x converter in.

Note: If the device was plugged in during execution of step 3, you need to manually unload the kernel module or reboot your system.